



**A. Demolition of Milbank Prestressed Flooring Units**

1. Milbank Prestressed flooring units are Pretensioned members. The tendons are embedded and bonded along the whole length of the unit and are cut flush with and exposed at the end of the unit; they do not have any end anchors.
2. Milbank Prestressed beams and slabs with can be demolished in a manner similar to ordinary reinforced concrete.
3. Milbank beams and slabs may be lifted and lowered to the ground as complete units after the removal of any composite concrete covering to tops and ends of the units.
4. Lifting the units from the structure should generally be done from points near the ends of the units or from lifting point positions. Reuse of lifting eyes, if in good condition, is recommended whenever possible.




Groups of "T Beams"



Single Prestressed Slabs


5. To facilitate breaking up with a hydraulic shear, the members should be turned on their sides.

**B. Milbank Prestressed Beam and Block Flooring Units**



150mm T Beam

Self Weight 34 kg/m



225mm T Beam

Self Weight 64 kg/m

**C. Milbank Prestressed Slab Flooring Units**

**75 or 100mm Solid Slab**

Self weight 216 kg/m    Self weight 288 kg/m

**150mm Light Hollowcore Slab**      Self weight 291 kg/m

**150mm Heavy Hollowcore Slab**      Self weight 349 kg/m

**200mm Hollowcore Slab**      Self weight 345 kg/m

**250mm Hollowcore Slab**      Self weight 400 kg/m